



VG H26-0068 1

ADVANCED MIRROR SYSTEM DEMONSTRATOR (AMSD)

PROGRESS UPDATE AT GOODRICH ELECTRO-OPTICAL SYSTEMS

Enrique Garcia

Goodrich Electro-Optical Systems
100 Wooster Heights Road
Danbury, CT 06810

**NASA Technology Days
Marshall Space Flight Center
May 22-23, 2002**

*NASA Technology Days
Marshall Space Flight Center
May 22-23, 2002*



- **Program Objectives and Requirements**
- **Goodrich Configuration Overview**
- **Progress Update and Status**
 - **Facesheet**
 - **Actuators and Controller**
 - **Reaction Structure**
 - **Assembly and Integration**
- **Test Plan and Program Schedule**
- **Summary and Conclusions**



Agenda



VG H26-0068 3

- **Program Objectives and Requirements**
- Goodrich Configuration Overview
- Progress Update and Status
 - Facesheet
 - Actuators and Controller
 - Reaction Structure
 - Assembly and Integration
- Test Plan and Program Schedule
- Summary and Conclusions



- **Diverse government applications require the benefits of:**
 - High-payoff large, light-weight mirrors
 - that advance the state of the art, and
 - are rapidly producible, and
 - are affordable
- **Specific objectives:**
 - Sub-scale demo of the mirror system technology
 - Traceable growth path to deployable, segmented optical systems
 - Provide design features that enable/improve the manufacture, integration, test, and performance of a broad range of operational systems



Summary of Requirements and Compliance (1 of 2)



VG H26-0068 5

<u>REQUIREMENT</u>	<u>STATUS/COMMENT</u>
<ul style="list-style-type: none">• Physical<ul style="list-style-type: none">- < 15 kg m⁻²- Hexagonal shape- 1.2m to 1.5m point-to-point	<ul style="list-style-type: none">~ 16.7 kg m⁻² (actuators + CRS repair)Comply (V-notch to eliminate fracture)Comply (1.3 m point-to-point)
<ul style="list-style-type: none">• Mechanical<ul style="list-style-type: none">- Fundamental frequency traceable to full-size flight mirror system	<ul style="list-style-type: none">Comply
<ul style="list-style-type: none">• Ambient Environment<ul style="list-style-type: none">- 290K to 310K- External mechanical disturbances	<ul style="list-style-type: none">ComplyComply
<ul style="list-style-type: none">• Cryogenic Environment<ul style="list-style-type: none">- 30K to 55K- No mechanical disturbances	<ul style="list-style-type: none">ComplyComply
<ul style="list-style-type: none">• Survival Environment<ul style="list-style-type: none">- 223K to 353K<ul style="list-style-type: none">• 25K to 353K (cryogenic)- 10g quasi static- 30g vibroacoustic	<ul style="list-style-type: none">223K to 324K (limited by adhesive)ComplyComply



Summary of Requirements and Compliance (2 of 2)



VG H26-0068 6

REQUIREMENT

STATUS/COMMENT

- **Total Surface Error**
 - 50 nm (rms); 250 nm (P-V) *Compliance expected*
 - Goal 25 nm (rms); 100 nm (P-V) *Achievable with additional CCP cycles*
- **Micro-roughness**
 - 40 Å (rms) *Compliance expected*
 - Goal of 20Å (rms) *Compliance expected (< 20Å typical for glass)*
 - Spatial periods 1 mm to 1 µm *Comply*
- **Prescription**
 - Off-axis parabola *Comply*
- **Vertex Radius of Curvature**
 - 10.000m ± 1mm *Comply*
- **Coating**
 - No coating required *Comply (no coating)*



Agenda




VG H26-0068 7

- Program Objectives and Requirements
- **Goodrich Configuration Overview**
- Progress Update and Status
 - Facesheet
 - Actuators and Controller
 - Reaction Structure
 - Assembly and Integration
- Test Plan and Program Schedule
- Summary and Conclusions

Architecture:

- Thin, light-weighted mirror facesheet
- Array of figure-control actuators
- Passive, stiff reaction structure
- Mirror facesheet CTE and DL/L matched to reaction structure for cryogenic performance





- **Figure-controlled (adaptive) mirror**
 - Reduces fabrication/test cost and schedule
 - Maximizes operational system applicability
- **Mirror facesheet CTE and DL/L matched to reaction structure**
 - Enables cryogenic performance
- **Multiple material options (mirror/reaction structure pairings) from a single architecture**
- **Design optimization to mission constraints**
 - Environment
 - Performance
 - Cost
 - Schedule
 - Actuator design is common
 - Mirror facesheet and reaction structure details are material dependent
 - Traceability assessments are material dependent
 - Influenced by specific application
 - Material dependent processes and facilities



- **Cost and schedule effective optical manufacturing**
 - Non-recurring investment in tooling, followed by rapid fabrication of multiple matched facesheets
 - Work with large tools for majority of processing time
 - Actuators for low spatial frequency correction
 - Computer Controlled Polishing (CCP) for remainder
- **Cost and schedule effective system-level operations**
 - Actuators provide radius and figure adjustment at test and operating temperatures
 - Flexible substrate allows increased shape correction
 - Reduced reliance on ground testing



Approach for Optical Fabrication: Stressed Mirror Polishing Overview



VG H26-0068 11

- **Basic fabrication process referred to as “Stressed Mirror Polishing” (SMP)**
 - R2 (backside) of optic is fabricated to a sphere
 - Optic is held, by vacuum, against aspheric blocking body
 - Blocking body asphericity is negative of desired R1 asphericity
 - R1 is polished to a sphere
 - When vacuum is released, R1 will “spring” to desired asphere
 - Touch-up polishing after mounting to actuators
- **SMP process has several advantages**
 - Spherical fabrication process is fast, smooth, and simple
 - Minimal optic handling reduces risk - most of the time the optic is mounted to granite blocking body
 - For multiple optics of same form, investment in blocking body paid off early




Fabrication of Fast Aspheres by SMP



VG H26-0068 12

- Taking advantage of thin section, bend the mirror to look like a sphere; grind and polish a sphere
- Large tools can remove material damage layer much faster
- Return to small-tool processing of unstressed asphere for final figure correction



Recurring and non-recurring efforts tailored based on quantity of units.



AMSD Approach Leverages Demonstrated Large Optical Systems Technology



VG H26-0068 13

- **HALO**
 - 3-meter diameter Primary Mirror Assembly
 - 30 kg/m²
 - tested at 100 Kelvin
- **LAMP**
 - 4-meter diameter Primary Mirror Assembly
 - room temperature High Energy Laser System
- **ALOT**
 - 4-meter diameter lightweight telescope for space operation
 - 70 kg/m² PMA
 - room temperature imaging system
- **LOS**
 - two four-meter diameter segments of 11-meter, f/1.25 primary mirror

Large, segmented mirrors and telescopes benefiting from shape-controlled technology are demonstrated.



Agenda




VG H26-0068 14


- Program Objectives and Requirements
- Goodrich Configuration Overview
- **Progress Update and Status**
 - Facesheet
 - Actuators and Controller
 - Reaction Structure
 - Assembly and Integration
- Test Plan and Program Schedule
- Summary and Conclusions



Light-Weighted Thin Facesheet:

- Facesheet design
- Optical fabrication (SMP)
- Light-weighting and edging
- Fracture and recovery
- Status







Facesheet Design



VG H26-0068 16

- Material is fused silica for CTE homogeneity (but could be ULE)
- Isogrid provides stiffness for 1-G support
- Isogrid provides flexibility for figure control






Optical Fabrication: Preparing the Blank for Optical Finishing




VG H26-0068 17




Water jet edging

Edged facesheet blank



Facesheet blank



*Fused silica facesheet
being prepared for
optical finishing.*



Facesheet grinding




Optical Fabrication: Preparing the Aspheric blocking Body




MS-0068 18

Aspheric BB in metrology



Aspheric BB Concept



Surface figured for
inverse asphere


Grooves in surface
vacuum distributi

for optic
nts

Bottom channels
for vacuum
plumbing

Vacuum Ports from
bottom channels to
surface grooves

Completed Aspheric BB






***Fabrication of aspheric
blocking body for SMP.***



Optical Fabrication: Optical Finishing by SMP



VG H26-0068 19



Metrology



*Optical fabrication by
Stressed Mirror Polishing (SMP).*



Optical Fabrication: Tooling for Water Jet Milling



VG H26-0068 20




***Preparing the tooling for
water jet light-weighting.***




Optical Fabrication: Light-Weighting and Edging




VG H26-0068 21




Light-weighted Facesheet



Water jet edging



Milling the pockets
into R2 surface



Milling & edging complete

***Light-weighting the
Facesheet by
water jet milling.***



Optical Fabrication: Fracture and Recovery




VG H26-0068 22

Fracture "repair"




Continued optical fabrication



Repair area excised during edging



Fracture during routine grinding of R2



***Optical fabrication completed as planned;
no loss of actuators.***




- **Facesheet Progress and Status:**
 - Fracture “repair” complete
 - Optical fabrication by SMP complete
 - Light-weighting by water jet milling complete
 - Edging by water jet complete
 - Beveling and stress relief in progress
 - Preparations for Facesheet Subassembly underway

***Optical fabrication complete;
Stressed Mirror Polishing advantages demonstrated.***



Actuators and Controller:

- Design overview
- Controller
- Test results
- Status



Bipod Assembly

Axial Assembly




Actuation System Design



VG H26-0068 25

- **Actuator assemblies (6 “Bipod”, 31 “Axial”) react all loads**
- **Similar to HALO (also cryogenic)**
- **Upper and lower diaphragm flexures stabilize translator & flexure, provide shear and moment load path for bipods**
- **Allows easy access to actuators for installation and servicing**





Actuator Design Parameters Summary



VG H26-0068 26

Performance Parameter	Reason
Stroke	Ground test and post-deployment capture range
Resolution	Performance (quantization)
Mass	Observatory flow-down
Reliability and Lifetime	Maintain low performance risk
Room and Cryogenic Performance	Operational performance and efficient ground-test strategy
Low (zero) Power Dissipation	Thermal maintenance Operational efficiency
Axial Stiffness	PMA Dynamics
Compatibility with Cryo-Appropriate Command/Power Structure	Minimize wire count for deployment Maintain reliability and redundancy


- **Goodrich has selected stepper-motor based actuator from Moog-Shaeffer Magnetics Division (SMD):**
 - Derived from NASA-funded cryo actuator studies
 - Engineered under Goodrich and Moog IRAD



Actuator Design: Space Rated Materials for Cryogenic Operation



VG H26-0068 27



Titanium Alloy (6AL-4V)	General Construction: Housing/Transducer, Motor Housing, Thrust Rod, Spring/Nut Element, Output Flange
Stainless Steel (440C)	Bearings, Harmonic Drive Wave Generator
Stainless Steel (Nitronic40)	Output Leadscrew
Stainless Steel (15-5PH)	Harmonic Drive Circular Spline and Flex Spline
Stainless Steel (416)	Motor Rotor

- Actuator internal bearings, harmonic drive wave generator, lead screw/nut use dry lubricant for low room temperature friction and excellent molecular bonding
- Materials are selected specifically for cryogenic application and compatibility
- Structural members are sized to perform over life with ample margin
- Fasteners are generally titanium with only a few 416 stainless steel (thermally matched)

***Performance demonstrated at 30K,
consistent with AMSD requirements.***





Actuator Design Verified at RT and Cryo



VG H26-0068 28

Room temperature tests:



Example Data:

- Average Step Size = 7.3 nanometers
- Standard Deviation = 3.5 nanometers
- Meets requirement for max. step size < 20 nanometers

RT vs. Cryo Performance:

- Same general behavior when unloaded
- Some units have exhibited anomalous behavior under load at cryo
- More extensive cryo tests underway



Actuator Electronics: Design Requirements



VG H26-0068 29

- **Architecture must be traceable to deployable, space-borne applications**
- **Minimize wire-count between nodes and central controller**
 - Hold actuator position with minimal actuator power
 - Minimize overall power dissipation
- **Architecture must be scaleable to large arrays of actuators**
- **Circuit design must be traceable to operation at 30K**
 - Operate over temperature range from 30 to 293K
 - Active devices MOS (bipolar processes freeze-out at $T < \sim 70\text{K}$)
- **AMSD Electronics design does not limit bandwidth**
($\gg 0.1$ Hz update rate)



- **Control Computer (CC) and array of actuator nodes form “ring”**
 - Serial communication minimizes wire count
 - Resistive isolation between nodes prevents fault propagation
 - Easily provides required throughput
 - Ultimate bandwidth limit is motor dynamics
- **All system “intelligence” in software executing on CC**
 - Directly commands motor windings to desired states
 - Operationally flexible, upgradeable
- **“Dumb” hardware at nodes**
 - Translate winding state commands to winding drive currents
 - Minimizes hardware complexity, maximizes system flexibility
- **Topology is inherently scaleable**
 - Change CC software required
- **AMSD drive electronics are “warm”
(located outside vacuum chamber)**





Actuator Electronics/Controller



VG H26-0068 31

AMSD 4-channel Actuator Driver Circuit Card



***Drive electronics, controller,
software and cabling are complete.***




- **Actuators/Controller Progress and Status:**
 - All 37 AMSD units have been delivered
 - Drive electronics and controller complete
 - Performance tests at RT complete
 - More extensive cryo testing under load underway
 - Integration of actuation components with Reaction Structure underway

***All actuators delivered;
basic design/performance verified.***



- **Composite Reaction Structure:**
 - Design and construction
 - Modeling
 - Delamination and repair
 - Cryo test results
 - Status





CRS: Design and Construction



VG H26-0068 34

- Graphite cyanate-ester for CTE match with glass Facesheet
- Mounts actuators and flexures; reacts loads from masses and figuring
- Interfaces to external mount
- Designed and manufactured by ATK





Photo of completed unit






CRS: Modeling and Analysis



VG H26-0068 35



- **NASTRAN Detailed Finite Element Model**
 - Layered shell elements
 - 37 concentrated mass elements representing actuators and INVAR fittings
 - Simple support at main mount locations
- **Predicted response of baseline structure meets requirement (1st mode reduced to due to repair)**






CRS: Delamination and Repair



VG H26-0068 36

- **Post cryo cycling inspection revealed voids in facesheets:**
 - Voids at specific orientation over core ribs
 - Attributed to alignment of facesheet plies relative to core cells
- **Repaired by composite straps between top and bottom facesheets:**
 - At every location of actual or likely delamination
 - Repair complete
 - CRS cryo cycled at the XRCF
- **Origin of failure and solutions identified**






CRS: Tests and Results



VG H26-0068 37

- **Tests conducted on repaired CRS:**
 - **Thermal cycle to 25 K at XRCF**
 - No metrology for distortion
 - No further delamination
 - **10-G static load test at ATK**
 - **Thermal characterization at XRCF**
 - Instrumented for distortion measurements
 - Two cycles to 25 K
 - Measured distortion within acceptable limits



CRS on cryo test stand at XRCF




- **CRS Progress and Status:**
 - **Fabrication complete**
 - **Delamination:**
 - Causes and solutions identified
 - Repair complete
 - **Cryo test of repaired unit complete**
 - **Integration with actuation system underway**

***CRS complete and verified by
analysis and measurement.***



- **Assembly and Integration:**

- Assembly description
- Integration process
- Status and Plans






Assembly Description



VG H26-0068 40






Hardware Integration Flow



VG H26-0068 41





- **Assembly and Integration Progress and Status:**
 - Design and process definition complete
 - Tooling design and fabrication partly complete and continuing
 - Reaction Structure/Actuator subassembly in progress
 - Preparations for Facesheet Subassembly underway

Assembly and Integration in progress per plan.



Agenda



VG H26-0068 43


- Program Objectives and Requirements
- Goodrich Configuration Overview
- Progress Update and Status
 - Facesheet
 - Actuators and Controller
 - Reaction Structure
 - Assembly and Integration
- **Test Plan and Program Schedule**
- Summary and Conclusions



Process Flow Summary



VG H26-0068 44






Test & Verification (RT at Goodrich)



VG H26-0068 45






Cryo Test Arrangements at the XRCF



VG H26-0068 46



MSFC provides:

- Interferometer
- Objective Lens
- Leica ADM
- Window
- DNC

Goodrich provides:

- In-chamber cabling for actuators & temp. sensors
- Out-chamber cabling for actuators
- Mirror Assembly temp. sensors
- Actuator Control Electronics & PC

MSFC provides:

- Vacuum feedthroughs
- Cabling to control room
- Temp. sensor's readouts
- 5 DOF positioning table

- Establish ambient baseline alignment
- Measure ambient baseline figure

Partially cool chamber

- Measure figure
- Adjust figure actuators as required to minimize figure error
- Track actuator and despace changes over temperature range

- Measure figure at cryogenic operating temperature





Top-Level AMSD Program Schedule

(as of 5/22/02)



VC 426-0068 47





Agenda



VG H26-0068 48

- Program Objectives and Requirements
- Goodrich Configuration Overview
- Progress Update and Status
 - Facesheet
 - Actuators and Controller
 - Reaction Structure
 - Assembly and Integration
- Test Plan and Program Schedule
- **Summary and Conclusions**



- **Our AMSD design is traceable to operational systems:**
 - **Flexible facesheet** *enables efficient figuring of a readily produced substrate*
 - **‘Displacement’ type actuators** *stiffen facesheet against reaction structure while providing shape control*
 - **Reaction structure** *utilizes a high stiffness-to-mass material that is amenable to efficient structural forms*
 - **Material choices** *can be tailored to specific applications (facesheet and/or reaction structure)*
 - **‘External’ actuator** *permits adoption of improved designs*
 - **Mass and stiffness changes** *are addressed without disruption to key facesheet/actuator design and manufacturing details*

Our AMSD design is fully traceable against the SOW requirements.




Summary



VG H26-0068 50

- **Goodrich's AMSD architecture provides robust accommodation for a broad range of system and mission requirements:**
 - Readily accommodates alternative petal geometries
 - Readily accommodates alternative materials
 - Provides opportunity to trade mass, stiffness, and segment size for optimal mission responsiveness
 - Manufacturing technique is cost/schedule effective for multiple builds

Rapid optical fabrication and isogriding have validated the recurring benefits of the AMSD manufacturing processes.





VG H26-0068 51

ADVANCED MIRROR SYSTEM DEMONSTRATOR (AMSD) AMBIENT AND CRYOGENIC TEST PLANS AT GOODRICH ELECTRO-OPTICAL SYSTEMS

Mark Furber

Goodrich Electro-Optical Systems
100 Wooster Heights Road
Danbury, CT 06810

**NASA Technology Days
Marshall Space Flight Center
May 22-23, 2002**


*NASA Technology Days
Marshall Space Flight Center
May 22-23, 2002*



Process Flow Summary



VG H26-0068 52






Test & Verification (RT at Goodrich)



VG H26-0068 53






Cryo Test Arrangements at the XRCF



VG H26-0068 54



MSFC provides:


- Interferometer
- Objective Lens
- Leica ADM
- Window
- DNC

Goodrich provides:

- In-chamber cabling for actuators & temp. sensors
- Out-chamber cabling for actuators
- Mirror Assembly temp. sensors
- Actuator Control Electronics & PC

MSFC provides:

- Vacuum feedthroughs
- Cabling to control room
- Temp. sensor's readouts
- 5 DOF positioning table





Test & Verification Plan (Summary)



VG H26-0068 55

• Ambient at Goodrich

- Install and align test article
- Verify software and electronic functionality
- Manual figure correction
 - Visual
- Determine noise levels (OPD, influence functions)
- Influence function measurement
- Optimize figure
 - Use measured influence functions
- Initial data reduction
 - Document results
- Pack and ship to MSFC

• Ambient and Cryo at MSFC

- Install and align test article
- Check out interferometer and software and electrical Interfaces
- Room temperature characterization as done at Goodrich
- Radius of curvature monitoring throughout
- Cryo Test
 - Cool down, adjusting figure intermittently as needed
 - At cryo:
 - Check actuator functionality
 - Manually optimize figure
 - Measure influence functions & associated noise
 - Optimize figure
 - Actuator/influence function characterization measurements
 - Return to RT, adjusting figure intermittently as needed
- Remove test article



(as of 5/22/02)

GOODRICH

VC H26 0068 56

