



Ball Aerospace  
& Technologies Corp.




## Cryo Testing of Coated SBMD Mirror

Ball Aerospace & Technologies, Inc.  
23 May 2002




# SBMD Met All Requirements - Areal Density and Optical Cryo Performance



0.53-m diameter,  
20 m RoC



19 nm rms figure  
at 38K



- SBMD Program successfully completed
  - Final briefing & test report, November 2000
- Beryllium substrate has excellent properties
  - Areal density  $< 9.8 \text{ kg/m}^2$
  - High stiffness-to-mass for acceptable 1-g testing
- Excellent optical performance at cryogenic temperatures demonstrated
  - Successfully tested from ambient down to 17K at MSFC
    - ambient to cryogenic surface figure shift  $< 89 \text{ nm rms}$
    - Stable cryo-figure  $< 19 \text{ nm rms}$
    - Print through  $< 6 \text{ nm rms}$



# SBMD Used to Examine Coating Distortion Effects




- Original SBMD program did not look at effects of cryo temperatures on coated mirrors
  - Task: Apply a protected gold coating to SBMD and retest at cryo
- To isolate the coating effects, the mount was modified to reduce cryo-figure mount induced distortion
  - Task: Modify mounting to:
    - Reduce mount induced cryo-figure distortion
    - Reduce variability after handling and cryo-cycling



# Modified Mounting System Stable and Lowered Cryogenic Distortion




Original Mount




No terms  
removed


New Mount




Residual pattern with new  
mount shows the amount of  
cryo-distortion from the  
original mount that was  
removed by cryo-figuring  
and now no-longer shows up  
with new mount



Surface Change = 89 nm rms    Surface Change = 53 nm rms



36 term  
Zernike fit  
removed



Surface Change = 11 nm rms

Surface Change = 17 nm rms    Surface Change = 17 nm rms


Measured change in ambient surface  
figure, before and after last  
cryogenic test, 6-rotation average



# Protected Gold Coating Successfully Applied to SBMD




- Mirror coated 6/7/01 at Denton Vacuum Inc.
  - Protected gold coating (coating is beautiful)
  - Coating passes humidity, adhesion and abrasion
    - Samples coated concurrent with mirror
  - Coating passed cryogenic shock test
    - Coated beryllium discs dunked in LN2
    - Passed tape test & no crazing after cryogenic shock
  - Coating calibration samples showed excellent uniformity



- Mirror shipped to MSFC for ambient optical testing
- Performed Cryogenic characterization



# Cryogenic Deformation of SBMD Small and Repeatable Before and After Coating






# Cryogenic Deformation Before and After Coating Shows Little Change




Cryogenic deformation  
before coating

No terms removed →




Surface Change = 53 nm rms

Cryogenic deformation after coating  
& 2nd mounting modification




Surface Change = 54 nm rms

36 term  
Zernike fit  
removed →



Surface Change = 17 nm rms




Surface Change = 23 nm rms





# Most of Change in Cryogenic Deformation Due to Modified Mounting



Change between cryogenic  
deformation before and  
after coating and  
modification of mounting  
Surface Change = 35 nm rms

NASTRAN prediction for  
modified mounting change  
Surface Change = 35 nm rms

Best estimate of only the  
coating effects  
Surface Change = 9 nm rms

Measured coating plus mounting  
effects minus the NASTRAN  
predicted mounting effect.






# Change in Cryogenic Deformation as a Result of Gold Coating




Mounting modification produced star-shaped residual pattern in previously cryo-figured mirror

Inner portion of difference map shows that coating of SBMD had no effect on the higher frequency print through measured in all previous SBMD tests



Surface Change = 35 nm rms  
Change in cryogenic  
deformation after coating and  
mount modification



Surface Change = 9 nm rms  
Change in measured cryogenic deformation  
over central 300 mm diameter region after  
coating and mount modification



# Summary of Additional SBMD Investigations



- New bipods
  - Resulted in significantly lower cryogenic distortion
    - 89 nm rms mounted to original flexure system
    - 53 nm rms mounted to new flexure system
  - Improved pre/post cryogenic test repeatability
- Coating
  - Proved negligible impact on ambient surface figure
  - Proved negligible impact on cryogenic surface figure
    - 53 nm rms cryogenic distortion before coating
    - 54 nm rms cryogenic distortion after coating
  - Proved negligible impact on cryogenic print through
    - < 9 nm rms change in high frequency component