






www.srs.com

Developments in Ultra Lightweight Membrane Optical Elements

Presented by Brian Patrick
Technology Days MSFC
May 23, 2002



Membrane Material for Optical Applications

CP1™ (Clear Polyimide)

- Developed by NASA Langley specifically for Space Applications
- Material Synthesized by SRS Under Exclusive License from NASA. (End to End Quality Control)
- Film Manufacturing Process Results in Very Homogenous Film Properties
- Wide Range of Operating Temperatures (Cryogenic - 250C)
- Resistant to UV Radiation
- Film Solubility Enables Advanced Casting and Surface Replication Manufacturing Techniques



Polymer Manufacturing Facilities

Primary Requirements for Precision Membrane Optics

Surface Finish


- A Highly Polished Specular Surface is Required to Transmit or Reflect Incident Light With Minimal Wave Front Distortion

Uniform Thickness

- Thickness Variations will Contribute to Figure Errors
- Stressed Membranes Assume the Figure of the Mid Plane


Figure Control

- Boundary Control
 - Rigid Ring
 - Compliant Ring
 - Active Tuning
- Distributed Loading
 - Electrostatic
 - Piezoelectric
 - Magnetic
 - Stress Coating




Membrane Thickness Variation Process Refinement


- Modifications to casting process has resulted in drastic improvement in thickness variation present on both flat and curved substrates.
- Sub-Wavelength Thickness Variation Demonstrated on Apertures Up To 0.5-meters.



Typical Membrane Material




Minimized Thickness Variation



Uniform Thickness Variation

Membrane Thickness Variation Process Refinement




**Double-pass
Interferogram of a
10cm Sample of CP-1**


**Thickness Uniformity
~1/20 wave rms.**

SRS Large-Scale Casting System

- New large-scale membrane facility has been installed at SRS and initial castings have shown similar success in thickness variation. Expandable up to 3-meter diameter castings.
- Currently Thickness Variation has been minimized to ~2 waves of error over 1.5-meters.



Center Strip of 1.5-meter Membrane Casting Prior to Facility Upgrade




Thickness Variation Composite of 1.5-meter diameter CP-1 Membrane revealing only ~2 waves of error.

Surface Roughness for SRS CP1™ Cast Membrane Films

rms	1.193	nm
Ra	0.898	nm


- 1.193 nm RMS Surface Roughness Demonstrated on 0.5 Meter Test Article
- Surface Roughness is Achievable on Precision Mandrel Replicated Films and Large Scale Net-Shape Films
- Air-Side of Membrane typically has superior surface finish than the casting substrate.



Surface Topography for SRS CP1™ Sample Cast from a Non-Precision Float Glass Substrate


Membrane Shape Management - Flats

Precision Thin Film Pellicles for Optical Bench Applications




Twyman-Green Interferometer consisting of CP1 beam splitter and mirrors

Membrane Shape Management – Curved, Stress Coated Membranes




Interferogram of 1.5-inch
diameter central region
of uncoated membrane




Interferogram of 4-inch
diameter central region
of uncoated membrane

Membrane Shape Management – Curved, Stress Coated Membranes




Interferogram of 1.5-inch
diameter central region of
coated membrane



Interferogram of 4-inch
diameter central region of
coated membrane

Membrane Shape Management – Curved, Stress Coated Membranes



Analysis of 1.5-inch
diameter central region of
coated membrane

Focus Term

Z3: 0.706139

ZERNIKE TERMS


Polynomial List

Z0: 0.763890	Z10: -0.15240	Z20: 0.397790	Z30: -0.04050	Z40: 0.000000
Z1: 0.066319	Z11: 0.519079	Z21: -0.03450	Z31: 0.185340	Z41: 0.000000
Z2: 0.115139	Z12: 0.007569	Z22: -0.02439	Z32: -0.05059	Z42: 0.000000
Z3: 0.706139	Z13: -0.01389	Z23: 0.194029	Z33: 0.045030	Z43: 0.000000
Z4: 0.127880	Z14: 0.307389	Z24: -0.27649	Z34: 0.083629	Z44: 0.000000
Z5: -0.02439	Z15: -0.35420	Z25: -0.01690	Z35: -0.04679	Z45: 0.000000
Z6: -0.08930	Z16: -0.10450	Z26: -0.00120	Z36: -0.00619	Z46: 0.000000
Z7: 0.345609	Z17: 0.017550	Z27: -0.07960	Z37: 0.000000	Z47: 0.000000
Z8: -0.40770	Z18: 0.024539	Z28: 0.011409	Z38: 0.000000	Z48: 0.000000
Z9: 0.028049	Z19: -0.04139	Z29: -0.00419	Z39: 0.000000	

All Data in Waves @ 633nm

Membrane Shape Management – Curved, Stress Coated Membranes


Focus Term Removed




All Data in Waves @ 633nm

Membrane Shape Management – Curved, Net Shape

- Replicated Spherical Optics Test
- 0.5-meter f/1.87 membrane
- Slight Vacuum used to seat film onto mount
- Ronchi Grating used to test membrane





16-Inch Spherical Test Article




Membrane Shape Management – Curved, Net Shape

- 0.5 lp/mm grating used at orthogonal positions
- Edge Loads and Out of Plane Loads Change Figure
- Analysis Shows Figure Error.
 - 39 micron RMS figure error for full aperture.
 - 7 micron RMS figure error for 20-cm aperture
 - Majority of figure error is membrane mounting non-uniformities and slight surface roughness on diamond turned seating ring on mount.
 - This figure error begins to approach the available correction range of adaptive optic systems currently in use such as the Real-Time Holography developed by the AFRL.




Membrane Shape Management – Curved, Magnetic

- SRS membrane has central area coated with magnetic material.
- The membrane is flat and of optical quality demonstrating $\sim 1/4$ wave flatness in central area.
- A magnetic actuator is placed behind the membrane.
- System is placed in ZYGO interferometer setup for surface figure measurement.



Membrane Shape Management – Curved, Magnetic



- As actuator moves closer curvature is produced in the membrane, primary error compared to flat is mainly Focus, some spherical..

Conclusions

- **Membrane Optical Elements, With Areal Density of 0.05 Kg/m² (Unsupported), Have Been Manufactured With Surface Finish and Thickness Tolerance Sufficient for Precision Optical Applications**
- **Practical Flat Membrane Elements Are Available Now. Additional Research Is Under way to Further Address Lightweight Support and Figure Control for Curved Optical Elements.**
- **Scaling Technology Exists to Create Very Large Aperture Membrane Elements of Optical Quality.**
- **Funding Sources – AFRL & NASA/MSFC**