

Conformal Membrane Reflectors for Deployable Optics

Patrick J. Hood Cornerstone Research Group, Inc. Dayton, OH 45440 937.320.1877

23 May 2002



- Company Introduction
- Program Outline
- Results
- Related CRG Technology
- Summary

CRG specializes in research and development of advanced materials and process technologies to enhance our customers' competitiveness.




Company History

- Founded April 1997 to conduct applied R&D of novel polymeric materials
- Bootstrapped: No partners or outside investors
- First commercial contract awarded February 2001 (35% of sales)



Company History Optical Materials (1997-present)

Latching Electrooptic Liquid Crystals



Reflective Membranes



Composite Mirrors






Company History Structural Materials (1998-present)


Syntactics



Inorganic Resins




Reactive Liquid Crystals





Company History Smart Materials (1999-present)

Shape Memory Polymers



Dynamic Modulus Composites






Medical

Technology

Technology Development

Market Driven





Industrial

Applications



Technology Matched with Customer Needs



Company Infrastructure

• 21,000-ft² Facility






- Polymer synthesis, formulation, & characterization
- Composite processing & characterization
- Interference microscope for surface characterization
- Clean room
- Laboratory automation & control using LabView software



Requirement: Large Membrane Optics



- Thermal Stability
- Low Areal Density
- High Specular Reflectivity
- Broad Bandwidth
- Radiation Hard
- Mechanically Robust




Chiral Liquid Crystal Reflectors


Fornerstone Research Group, Inc.



Nematic


Smectic






Cholesteric

Discotic








Transmitted Light:


Left-Handed
Circularly Polarized

Chiral Optical Characteristics

Reflected Light: Right-Handed


Circularly Polarized








Wavelength Selection



Composition Controls Wavelength




Free-Standing Membranes






Polymer Reflector Performance





Conformal Processing





Tornerstone Research Group, Inc.

Phase I
Coupon Scale
LCP Devices

LCP Film,
Monodomain
Broadband
Reflector

LCP Membrane, Monodomain Narrowband Reflector

Program Objectives

Phase II
Prototype Mirror


LCP Membrane,
Monodomain
Broadband Reflector:
Coupon



LCP Membrane,
Monodomain
Broadband Reflector:
1 m Prototype Mirror



Phase I Work Plan





Task 1-1: Monodomain Broadband Film


- University of Rochester effort -- Prof Shaw Chen
- Developed monodomain LCP broadband reflective film
 - Cross-linked cholesteric LCP
 - Formulated with commercially available monomers
 - Polymerization yields graded pitch of molecular structure -- broadening the reflection band
 - Homogenous film with good alignment
 - Transitioned fabrication process technology to CRG
- Achieved broadband specular reflectance

Reflectance near theoretical maximum of 50% for single layer material

CRG


Task 1-1:

Monodomain Broadband Film



CRG

Task 1-1: Monodomain Broadband Film



Specular Reflection in Monodomain Broadband Device (XLCP film on 2.5 cm diameter glass substrate)

Monodomain Narrowband Membranes


- Developed monodomain LCP narrowband reflective membrane
 - Cross-linked cholesteric LCP formulated with commercially available monomers
 - Photopolymerization process
 - Homogenous material with good alignment
- Developed process for releasing membrane
- Achieved narrowband specular reflectance in free-standing membranes

Reflectance near theoretical maximum of 50% for single layer material



Task 1-2:

Monodomain Narrowband Membranes






Cured XLCP Material Before Release from Glass Substrate



Task 1-2:

Monodomain Narrowband Membranes




XLCP Membrane
After Release from Glass Substrate

(4.5 cm diameter, 13 micron thickness)

1 ask 1-2:



Monodomain Narrowband Membranes






XLCP Membrane
Before (L) & After (R) Release from Glass Substrate
(7.5 cm diameter, 13 micron thickness)



Task 1-2:

Monodomain Narrowband Membranes



Reflectance of LCP Narrowband Membrane




Task 1-4: Determine Radiation Effects

- International Photonics Consultants, Inc., accomplished gamma irradiation tests
 - Used polydomain narrowband XLCP material as analog to monodomain materials
 - Timing required radiation test before monodomain material would be available
 - Chemical compositions closely related
 - Exposures: 10 krad, 50 krad, 100 krad
 - Pre- & Post-Irradiation characteristics compared
- Results: Small radiation effect requiring further study



Task 1-4: Determine Radiation Effects





Transmission of Polydomain Device

Before & After Gamma Irradiation


- Company Introduction
- Program Outline
- Results
- Related CRG Technology
 - Summary




Collapsable SMP honeycomb

deploys to provide structural stiffness.

NRO 2001 DII Program Overview





Task 4: Integrated Active Damping




PVDF devices distributed within deployable EM reflector provide active damping of vibrations over broad frequecy ranges.

Program Goal Use strain recovery property of Shape Memory Polymers to achieve self-deployable high-performance, phase corrected optical sensors for space applications



Tailoring SMP Mechanical Properties





NRO 2001 DII Optical Quality SMP Surface




Styrene-Based SMP Reflector with Gold Coating (12.7cm dia, 2.5cm thickness, ≈400 Å coating)



NRO 2001 DII Optical Quality SMP Surface






SMP Activation Sequence (approximately I minute)



NRO 2001 DII SMP Support Structure



Compression Molded SMP










NRO 2001 DII SMP Phase Corrector

Goal:

Design and demonstrate microactuator array to correct for post-deployment wavefront distortion



Approach:

Microstructure SMP arrays actuated via laser diode



NRO 2001 DII SMP Phase Corrector

Laser Radiation

Experimental Approach

- Design SMP & dye
- Fabricate microactuator array
- Compress
- Actuate with laser diode

Activates Individual
Microactuators


Memory State

Activates Individual


Microactuators




NRO 2001 DII SMP Phase Corrector




1 mm x 1mm



Phase Corrector with Partially Flattened Microactuators



1 mm x 1mm



Phase Corrector with Single Activated Microactuator




Multi-Functional Composites

Features

- Automated process
- Multilayer, multicomponent
- Advanced materials
- Increased design flexibility






Applications

- Solid rocket motors
- Radomes
- Limited collateral damage weapons



Composite Mirrors



Air Force 2002 SBIR Phase I



High-Performance Syntactic Composites



Features


- 0.55 g/cc
- High specific strength
- Superior integrity

Applications

- Strong lightweight spacers
- Insulatory propulsion components
- Missile radomes



Inorganic Resin: Polysialate




poly(sialate-siloxo)

Applications

- Propulsion components
- Space-based mirrors
- Secure electronics


Features

- Castable
- Low temperature cure (60°)
- Low cure shrinkage





Polysialate Surface Finish



AT-P502B Title :Polysialate Statistics of Surface: Part ID :P5028 0.02um Area: 753,886686,41un 0.11um ADE/PHASE SHIFT Customer : -0.11um 0.02um Mag : 10.1 Operator :AT MapVue EX - Surface MappIng Software 0.ZZun -0.30 DATE: 04-24-2002 Rek: Fleld-5 : Version 6.35 (c) 1985-2001 PT: 345763 **R**ku: 3.16 TIME: 09:51:41 F[eld-6 Terms Subtracted: Connent :



- CRG Achieved Phase I Gossamer Objectives
 - Demonstrated LCP Film Broadband Reflector
 - Demonstrated LCP Membrane Narrowband Reflector
- Other CRG Technologies Support Future Space-Based Imaging Applications
 - Shape Memory Polymers
 - Dynamic Modulus Composites
 - Multi-Functional Composites
 - Composite Mirrors
 - High-Performance Syntactic Composites
 - Polysialate Composites