

Advanced Metrology for Atypical Surfaces

Marc Tricard and Paul Murphy

QED Technologies, Inc.

1040 University Avenue • Rochester, NY • USA

Tel: +1 (585) 256-6540x120 • Fax: +1 (585) 256-3211

tricard@qedmrf.com • www.qedmrf.com

Acknowledgements:

Jim Kirsch



Weapons Science Directorate
US Army Aviation & Missile
Command

Advantages of subaperture stitching

- **Use of smaller interferometers**
 - ◆ Shorter air path (concaves) (use long radius diverger)
 - ◆ Smaller transmission optics (convex)
- **Higher lateral resolution**
 - ◆ Subaperture has the full interferometer resolution, so the stitched result can have more than that
- **Calibration of systematic errors**
 - ◆ Part motion allows reference wave and other calibrations
- **Avoid null optics for aspheric testing**
 - ◆ Again, the subaperture has the interferometer capability, so the stitched result can have more
 - ◆ Thus a high enough magnification with enough subapertures can non-null test an asphere


Stitching background and motivation

- **Background – subaperture stitching is not new**
 - ♦ Low-order polynomial fit to non-overlapped subapertures
 - ♦ Microscope pair-wise stitching
 - ♦ Zonal (annular subaperture) asphere testing
 - Translation along aspheric caustic to match local radius
 - ♦ Large, high-resolution plano optics
 - Simultaneous optimization of DC and tilt of all subapertures



The SSI System



- **4" or 6" Zygo GPI Interferometer**
- **6-axis computer controlled workstation**
 - ♦ Engineered in cooperation with Schneider Opticmachines
- **QED patented techniques and advanced software**
 - ♦ Motion control
 - ♦ Interferometer control
 - ♦ Stitching algorithms
 - ♦ Automation



Innovative Metrology: SSI

Subaperture Stitching Interferometer

- **Full aperture measurement of large NA & CA parts**
- **Completely Automatic**
 - Auto-Positioning, nulling, & radius testing
- **Intuitive & Easy to Operate**
 - Reference wave, distortion, pixel scale calibration



SSI measurement example

Aperture – 148.34 mm (5.84")

Radius – 82.55 mm (3.25")

CT – 3.04 mm (0.12")


Sag – 50.39 mm (1.984")

Objective - Zygo 4" f/1.5


Subaperture = 55.1 mm

Required 25 subapertures –

(4 center, 9 inner, 12 outer)




Inner Ring




Outer Ring



Center



The Stitched Result



Radius: 82.6 mm

Surface:


PV – 1.649λ (@ 633nm)


Rms – 0.187λ (@ 633nm)

Total measurement time:

12 minutes!!

The Reference
Wave Error





Surface/Wavefront Map

µm

+0.20000

-0.20000

PV	0.291 µm	rms	0.04301 µm
Size X	32.16 mm	Size Y	32.16 mm
Auto Aperture	On	Aperture (D 141:	93
Manual IIS	Off		

Date/Time: 11/11/2011 11:11:11 AM

File Name: AA_FTHRU25 full.dat

Stitching algorithm

- ❖ Minimizes mismatch in overlap regions by adding an optimal amount of error compensation
 - ❖ Free compensators: vary in each subaperture
 - ❖ Traditional alignment errors: piston, tilt, power
 - ❖ But other errors can be included, e.g. translation, orientation
 - ❖ Interlocked compensators: same in each subaperture
 - ❖ Reference wave error (as a Zernike polynomial series)
 - ❖ Geometric distortions of viewing system
 - ❖ Does not require separate calibration procedure to determine and separate systematic errors from stitched results!

$$F_j(x,y) = f_j(x,y) + DC_j + Xtilt_j x + Ytilt_j y + Power_j (x^2 + y^2)$$


$$F_j(x,y) = f_j(x,y) + \left[\sum_k a_{jk} g_{jk}(x,y) \right] + \left[\sum_i \alpha_i G_{ji}(x,y) \right]$$

Example of stitching-computed reference wave

Reference wave
compensation


OFF

full aperture



PV 24.2 nm
rms 3.71 nm


rms mismatch




PV 12.2 nm
rms 4.56 nm

reference wave


ON



PV 21.6 nm
rms 3.10 nm



PV 6.64 nm
rms 1.05 nm



PV 34.8 nm
rms 4.34 nm




Metrology performance – stitched vs. full-aperture

Comparison of stitched and
full-aperture
measurements




\varnothing : 38 mm R: 41.23 mm

R/ 1.09




Full-aperture measurement using TS 4" f/ 0.75

reference wave (two-sphere calibrated)



PV: 14.7 nm rms 2.19 nm


test surface



PV: 36.6 nm rms 3.72 nm


Stitched measurement using TS 4" f/ 1.5

Stitched test surface




PV: 33.0 nm rms 3.64 nm

Difference from full aperture measurement



PV: 6.68 nm rms 0.66 nm


rms mismatch



PV: 3.46 nm rms 1.17 nm


Stitched measurement using TS 4" f/ 3.3

Stitched test surface




PV: 28.9 nm rms 3.18 nm

Difference from full aperture measurement



PV: 10.4 nm rms 1.32 nm


rms mismatch




PV: 4.51 nm rms 1.05 nm

Stitching merits for large mirrors

- Boosted testable aperture sizes (i.e. cost-effective reference optics)
- Boosted testable aspheric departure (can alleviate need for nulls)
- Boosted accuracy (from thorough, automated calibration of reference wave, distortion, retrace, etc.)
- Boosted resolution
- Reduced non-common air path for long-radius concaves
- Dominant uncertainty well matched to adaptive mirrors





Advanced Metrology for Atypical Surfaces

Marc Tricard and Paul Murphy

QED Technologies, Inc.

1040 University Avenue • Rochester, NY • USA

Tel: +1 (585) 256-6540x120 • Fax: +1 (585) 256-3211

tricard@qedmrf.com • www.qedmrf.com

Acknowledgements:

Jim Kirsch

Weapons Science Directorate
US Army Aviation & Missile
Command