

Development of a Laser Micromachining Process for the Fabrication of SiC Mirrors

Technical Monitor: Dr. Lawrence Matson

MDA Phase II SBIR Contract # W9113M-06-C-0117

Mound Laser & Photonics Center, Inc.

Ron Jacobsen (P.I.)

Larry Dosser, Scott Cornell,
David Beeler, Chris Taylor



Distribution A: Approved for Public Release.
Distribution Unlimited. Copyright © 2009 MLPC

Contract Status

- Phase II concluded in December 2008.
- MDA Transition funding award for one full year additional effort announced August 2008.
ETA = February 2009.
- Transition funding not yet awarded.
ETA now June 2009.
- This presentation represents about 4 months worth of update relative to last year's presentation.

Program Goals

- Gain practical understanding of pulsed laser ablation of SiC materials being considered for mirrors.
 - Ablation rate
 - Roughness
 - Machining quality
 - Damage Mitigation
- Develop metrology guided laser micromachining algorithm for arbitrary shaping (e.g. aspheres) of SiC blanks
- Develop laser micromachining workstations for practical mirror shaping.


Laser and Materials

- Picosecond pulsed laser for direct ablation
 - Avoids thermal effects
 - Damage free
- SuperRAPID by Lumera
 - Pulse duration ~10-14 ps
 - Wavelength choices 1064, 532, 355 nm
 - Pulse frequency from 10 – 640 kHz
 - Nominal max power = 10W (a 50W version will be available soon.)
- Experimentation focuses on two SiC materials
 - Trex SiC: relatively smooth initially
 - Poco SuperSiC-2: very rough, but easy to make near net shape

Direct Focus Workstation





- Integrated by JPSA
 - Four axis (X,Y,Z, θ)
 - Direct focus, position synchronized laser firing
 - smaller laser spot, < 2 μm accuracy
 - Scan head
 - Faster operation, ~ 20 μm accuracy
 - Vision system
 - 6" turntable
- Enables
 - Greater positioning accuracy
 - Polar machining θ .
 - Room to add in situ metrology.



Metrology Guided Micromachining

MLPC and Wright State University, developed software to guide the laser workstation based on metrology of original surface.

- **Input:** Height map of surface from White light interferometry.
- **Output:** Laser path commands that machine the pattern below into a flat surface.





Metrology Guided Mirror Machining

- Inputs
 - Height map of original surface.
 - Mirror-shape equation.

$$Z = \frac{CS^2}{1 + [1 - (K + 1)C^2S^2]^{1/2}}$$


- Output
 - Command file specifying laser paths and firing times needed to ablate from current shape toward final shape.



Machining on Direct Focus Workstation: Example 1.

When executing polar machining ON center ...


- Machining is faster because the laser is always over the target.
- However, center is not accessible as there is a minimum radius at which appropriate laser pulse overlap can be maintained.
 - Appropriate for component that don't use center.
 - Or, a finishing step can remove the central plateau.



Machining on Direct Focus Workstation: Example 2.



When executing polar machining OFF center ...

- Plateau in center is avoided.
- Machining is slower as laser is off target for most of each revolution.
 - Efficiency could be increased by machining multiple parts per revolution.



Polishing Compatibility

- An extensive study was undertaken in cooperation with QED to determine how much laser ablation induced roughness of SiC could be tolerated before polishing.
- Began with Trex SiC polished to ~ 4 nm Ra.
- Laser ablated regions of sample with varying pulse energy and raster pattern to create surfaces with roughness from 10 nm to > 10,000 nm.
- Sample was then given to QED for MRF polish.




$R_q = 6.7 \text{ nm}$

Polishing Compatibility




- Areas with laser induced Ra < 100 nm were readily polished back to the original Ra ~ 4 nm.
- Areas with Ra > 400 nm could be mitigated by polishing, but could not be returned to original smoothness, primarily due to pitting
- This puts a constraint on a laser machining process to maintain sufficiently low Ra



Stress/Damage Mitigation



- Tests of picosecond ablation on Twyman stress of SiC ongoing in collaboration with Dr. Joseph Randi at EOC.
- Interferometry used to measure distortion of 50 mm diameter, thin, round disks after surface ablation.
- Figure shows example of how disk faces distort after ablation, consistent with removal of compressive stress left by polishing/grinding.
- Also using Raman to quantify distortion – still early in that work.



Twyman Distortion vs. Ablation



- Distortion with each ablation can be quantified by change in the optical power ($\sim 1/R$) of each face.
- Comparable DP on first ablation, independent of ablation depth
 - Is depth of stress layer much thinner than previously thought?

		Ablation #				
Sample		1 st	2 nd	3 rd	4 th	5 th
#2	Incr. Depth (nm)	6	0	15	15	
	ΔP (km ⁻¹)	11.7	-0.1	3.4	0.7	
#3	Incr. Depth (nm)	20	15	0	15	15
	ΔP (km ⁻¹)	10.5	-0.1	0.3	0.5	0.2
#6A	Incr. Depth (nm)	40	40	60	40	
	ΔP (km ⁻¹)	6.9	3.2	-2.8	1.4	
#6B	Incr. Depth (nm)	6	0	15		
	ΔP (km ⁻¹)	-5.2	-0.1	-5.7		
#34	Incr. Depth (nm)	400				
	ΔP (km ⁻¹)	10.5				

Ablation Rates



- Ablation at UV and IR wavelengths show similar behavior.
 - Threshold for ablation $\sim 0.2 - 0.3 \text{ J/cm}^2$
 - Material removal per pulse grows logarithmically at low fluence, consistent with simple Bayes formula for optical penetration.
 - Above $\sim 3 \text{ J/cm}^2$ the material removal increases quadratically, and machining quality is poor. In this regime, each ablation pulse is probably getting a thermal assist from its overlapping predecessors.



Upcoming Transition Tasks

- Machining demo components for SiC Afocal Telescope (SCATS)
 - Reduced size primary mirror
 - Full-scale tertiary mirror
- Application to mating surfaces.
 - E.g., pin and pad
 - Micron tolerances required.
- Integration of metrology into workstation
 - Benchtop white light interferometry
 - Confocal microscopy
- Some work on modeling picosecond pulsed laser ablation with Illinois Institute of Technology.



Conclusions

- Demonstration machining with direct focus workstation underway.
- Polishing compatibility study has defined limits of aggressiveness that can be used during laser ablation.
- Twyman testing continues to elucidate the degree to which grinding damage can be mitigated by ablation. This may be a process with spin-off value.
- Technology transition program to commence shortly and run for upcoming year.