
Quantitative Assessment of Homogeneity in SiC Mirrors via Ultrasound NDC

R.A. Haber


V. DeLucca

S. Bottiglieri

Mirror Days


June 2011

What is Ultrasonic NDE



- Immersion-based, pulse-echo system
- C-scan imaging mode useful for mapping material property variations


- Property mapping completed in ~20mins. for a 4" x 4" scan area
- TOF related to c , ρ , v , E , G , K and Z
- Higher TOF corresponds to lower velocity and therefore lower elastic properties



Amplitude attenuation caused by scattering/ absorption of ultrasound energy

Evaluation-Based Measurements


A-scan for Point Measurements



Evaluation-Based Measurements

C-scan Mapping

C-scans for Area Property Maps



- Determining elastic property variations
- Sensitivity of porosity variations

• Spatially locating large, anomalous features

C-scans → Sensitive to sample nonuniformities

- Surface scratches 100μm and greater apparent
- Thickness gradient of 100μm and greater apparent


➤ Attenuation Coefficient Map

➤ Sample thickness greater than 2"

➤ Porosity greater than 10%


• 4" x 4" tile scan in 30 minutes

homogeneity of entire sample



C-scan maps useful for determining **elastic property variations**, **large defects**, **homogeneity of entire sample**

Ultrasonic Transducers



Piezoelectric Effect:


Electric Potential



Crystal Deformation and Oscillation




- Used to emit and receive ultrasonic pulses
- Pulse created by piezoelectric crystal or ceramic
- Each transducer emits over a range of frequencies dependent on piezoelectric crystal size, geometry, and backing material

Transducer Output




Phased Array Fundamentals


- Probe consists of multiple elements, controlled independently
- Beam profile adjusted by firing elements at different times
- Focus beam on points or planes of different depths
- 10x faster than conventional ultrasonics



ELEMENT PATTERNS




Phased Array Probe Cross-section





*Images taken from Olympus-ims.com

Where NDE Take Us and Where It Stops


Sintered SiC



Glass-Ceramic



CVD SiC



Reaction Bonded SiC


- C-Scan mapping of acoustic velocity and amplitude variations
- Rapid identification of anomalous defects

**NDE tells us *where* and *how*
sample properties vary**

- NDE identifies anomalous defects
 - Composition?
 - Effect on local microstructure?
- NDE measures elastic properties
 - Relate to density
 - New batch compositions introduce elements that reduce density but improve microstructure
- Which values are 'good'?
- What is the cause of variations?
- Are features seen in UT detrimental to performance?
- Do subtle variations matter?
- Feature Size?

**NDE leaves us with
*unanswerable questions***

Characterization-Based Measurements



Absorption Dominant Regime

Scattering Dominant Regime


Approximate absorption and scattering regimes for silicon carbide

Absorption: up to ~50MHz when grains are <10 μ m

Analogous to XRD, etc. Need Multiple Standards

Scattering: Dominates higher frequencies

Acoustic Attenuation Regimes



- ❖ $I \rightarrow$ concentration
- ❖ $f_0 \rightarrow$ feature type and mean size
- ❖ $\gamma \rightarrow$ pinning condition

- ❖ $m \rightarrow$ elastic mismatch and morphology
- ❖ $n \rightarrow$ mean size

Absorption at low frequencies \rightarrow Peak-like behavior


Scattering at high frequencies \rightarrow Power-law behavior

Wavelength to Scatterer Size ~ Visual Representation


In SiC, wavelength is 150 – 1200 μ m
for frequencies between 10 – 80MHz

α : attenuation coefficient
 a : mean grain size

f : frequency
C parameters: scattering constants




Rayleigh Regime



$\lambda > a$
When a is less than
approximately $\lambda/10$

$$\alpha = C_R a^3 f^4$$


Stochastic Regime



$\lambda \approx a$
When a is approximately
the same size as λ

$$\alpha = C_S a f^2$$


Diffuse Regime



$\lambda < a$
When a is
larger than λ

$$\alpha = \frac{C_D f^0}{a}$$

Thermoelastic Intraparticle Absorption



- As wave propagates, bound particle bends
- One side of the particle in compression, the other side in tension
- Differential heating occurs → thermoelastic effect
- Equilibrium only reached by taking energy from acoustic wave, causing attenuation
- Frequency of maximum attenuation defined as:

Acoustic State of Particle through particle

Particle is bound on both ends elastically by adjacent grains

Zener Equation

$$f_o = \frac{\pi X}{2 \rho C_V a^2}$$

X – thermal conductivity

ρ – density

a - diameter


C_V – specific heat

Thermoelastic Interparticle Absorption

- Acoustic wave propagates from a single direction
- Anisotropy in properties leads to differential heating depending on orientation
- Irreversible heat flow occurs
- Energy required for equilibrium taken from acoustic wave, causing attenuation
- Frequency of maximum attenuation defined as:

$$f_o = \frac{3 \pi X}{2 \rho C_v a^2}$$

X – thermal conductivity
 ρ – density
 a - diameter
 C_v – specific heat




Acoustic wave propagates through particles
 Differential heating occurs depending on orientation

Which mechanisms are active?
 Is this a concern for biphasic materials?




Previous Acoustic Spectroscopy Results

Fully Dense Monolithic Sintered Silicon Carbide

20MHz α C-Scan




α Spectra at
Each Point




Automated Least Squares Regression Analysis for Predicted Solid Inclusion Size Distributions

Motivation for Nondestructive Testing of Mirror Materials








Can we
determine
quality before
deployment?



- Cost
 - ❖ Evaluate before polishing
 - Go/ no-go criteria for continuing
 - ❖ Evaluate after polishing
 - Determine errant polishing defects, degree of polishing
- Failure
 - ❖ Location of large anomalous defects
 - ❖ Microstructural characterization of grain, solid inclusion size
 - Effects of thermal , mechanical stress, vibratory stresses

Samples


Sample	Manufacturer	Material	Condition	Form
I, II, III	St. Gobain	Sintered SiC	unfinished	lightweighted, planar blanks
01	SSG	RB-SiC	polished	lightweighted, planar mirror
02	M Cubed	RB-SiC	polished	lightweighted, planar mirror
03	Schafer	SiC foam core, Si coating	polished	lightweighted, planar mirror
A, B, C, D	SSG	RB-SiC	polished	planar flats




How Can We Evaluate These?

Ultrasound Nondestructive Testing of Mirror Blanks

Sintered SiC Lightweighted Unfinished Planar Blanks




- 20MHz C-Scan maps to determine:
 - Surface Irregularities
 - Bulk Defect
- Sintered silicon carbide mirror blanks
 - As ground, before polished
- Show relative uniformity and reproducibility between samples
- Any large irregularities caused by sample support structure
- Relate NDE before and after polishing




Comparison of Single Element and Phased Array

Lightweighted Planar Polished Mirrors



Top Surface Amplitude Bottom Surface Amplitude

20MHz



Top Surface Amplitude




- Phased array C-Scans performed much faster than single element
 - Phased array detects more surface/subsurface irregularities
 - Both phased array and single element show similar results for bottom surface
-
- Phased array shows scanning artifacts and distortion of images
 - Phased array probes limited to relatively low frequencies compared to single element transducers
 - Single element transducer shows much higher spatial resolution

Ultrasound Evaluation for Subsurface Uniformity

Single Element Amplitude Testing of Various SiC Mirrors

Mirror 01



20MHz



Amplitude gradient →
Density, thickness gradient
Location of large defects

Mirror 02


5MHz



Reaction Bonded SiC Mirror Samples

Reaction Bonded SiC Polished Planar Flats

A




20MHz

75MHz

C_L

B




20MHz

75MHz

C_L

C




20MHz

75MHz

C_L

D



20MHz


75MHz

C_L

- **Attenuation coefficient show variability in bulk material**
 - At 20MHz, appear as darker red regions of higher attenuation within lighter orange and yellow background
 - Clearer at 75MHz, features of yellow or orange in lighter blue/green background
- **Inverse relationship with α and C_L**
 - Indicates presence of unreacted silicon within microstructure \rightarrow lower speed of sound, high α in those regions
 - Gradient in speed of sound \rightarrow possible gradient in density

Reaction Bonded SiC Mirror Samples


Attenuation Spectra



Absorption between 11 – 23MHz

- Silicon grains:
 - Intraparticle: 2.5 – 3.6 μm
 - Interparticle: 7.5 – 10.8 μm
- SiC grains:
 - Intraparticle: 2.2 – 3.1 μm
 - Interparticle: 6.6 – 9.3 μm

- Power law exponent of ~ 4 - indicative of predominantly Rayleigh scattering
- Suggests grain size is much smaller than the wavelength (135 – 270 μm), so the SiC grains should be 5 – 10x smaller: 13.5 – 54 μm
- **Attenuation appears to be caused by interparticle absorption by Si grains and scattering by SiC grains**



Summary

- Reviewed features that can be observed with high resolution using ultrasound:
 - Surface and subsurface irregularities using amplitude scans
 - Bulk defects using attenuation coefficient scans
- Ultrasound can be used to nondestructively characterize mirror materials prior to polishing and deployment
 - Microstructural information can be used to predict if the mirror will perform well in service

State of the Art

- Single transducers with frequencies $>100\text{MHz}$, using attenuation measurements to determine grain size, composition
 - Limited to flat surfaces, regular geometry
- Phased array can find acoustically different phases using conventional ultrasound methods, even on curved surfaces
 - Currently limited to lower frequencies

Acknowledgements

Ceramics, Composite, and Optical Materials Center

ARL Materials Center of Excellence – Lightweight
Materials for Vehicle Protection

USAF Grant No. FA8650-08-C-5205

St. Gobain, SSG, M Cubed, Schafer