

Reducing Mid-Spatial Frequency (MSF) Errors with VIBE Finishing

Review of Two Phase I SBIR Projects
Outline for Phase II SBIR – contract started June 7th

Jessica DeGroote Nelson, Kate Medicus, Alan Gould and Mike Mandina

Optimax Systems, Inc.
Ontario, NY
www.optimaxsi.com

Work funded by NASA Phase I and Phase II SBIRs

SBIR Data Rights

Order/Contract Numbers: NNX10CF20P, NNX11CH31P and NNX1CB95C

Expiration of SBIR Data Rights Period: June 22, 2017

The Government's rights to use, modify, reproduce, release, perform, display, or disclose technical data or computer software marked with this legend are restricted during the period shown as provided in paragraph (b)(4) of the Rights in Noncommercial Technical Data and Computer Software—Small Business Innovative Research (SBIR) Program clause contained in the above identified contract. No restrictions apply after the expiration date shown above. Any reproduction of technical data, computer software, or portions thereof marked with this legend must also reproduce the markings.




Outline

- Introduction
 - Mid-Spatial Frequency (MSF) Errors
 - VIBE Technology
- Characterization of MSF Errors
- MSF Error Removal with VIBE

Outline

- Introduction
 - Mid-Spatial Frequency (MSF) Errors
 - VIBE Technology
- Characterization of MSF Errors
- MSF Error Removal with VIBE


What is “mid-spatial frequency”?



J.E. Harvey and A. Kotha, “Scattering effects from residual optical fabrication errors, Proc. SPIE 2576-25

D. Aikens, J. E. DeGroote, and R. N. Youngworth, "Specification and Control of Mid-Spatial Frequency Wavefront Errors in Optical Systems," (Optical Society of America, 2008).


Figure is the range of spatial frequencies addressable with a simple Zernike expansion



D. Aikens, J. E. DeGroot, and R. N. Youngworth, "Specification and Control of Mid-Spatial Frequency Wavefront Errors in Optical Systems," (Optical Society of America, 2008).


J.E. Harvey and A. Kotha, "Scattering effects from residual optical fabrication errors, Proc. SPIE 2576-25

Finish (a.k.a “gloss” or “roughness”) is typically less critical as it results in total transmission loss



J.E. Harvey and A. Kotha, "Scattering effects from residual optical fabrication errors, Proc. SPIE 2576-25


Mid-Spatial Frequency bandwidth limits help to define the MSF itself



J.E. Harvey and A. Kotha, "Scattering effects from residual optical fabrication errors, Proc. SPIE 2576-25


Example: Spoke and Spiral Errors

PV: 179.9nm
RMS: 28.6nm




Unfiltered data

PV: 152.8nm
RMS: 26.3nm




Low spatial
frequency

PV: 41.9nm
RMS: 4.8nm



Mid-spatial
frequency

PV: 17.1nm
RMS: 0.6nm



High spatial
frequency

D. Aikens, J. E. DeGroote, and R. N. Youngworth, "Specification and Control of Mid-Spatial Frequency Wavefront Errors in Optical Systems," (Optical Society of America, 2008).

VIBE Process is a high-pressure, high-speed, full aperture polishing process


Optic slowly oscillates while in contact with vibrating lap

Full-aperture, conformal lap vibrates at high frequencies




VIBE linear motion with over-stroke

Vibe linear motion with over-stroke





Copyright 2010 Optimax Systems, Inc., All rights reserved; Media #M0328



Animation speed and motion has been exaggerated for viewing purposes

VIBE originally intended for pre-polishing glass spheres and aspheres



Initial 9T alumina
ground surface



After 10 minutes of VIBE
polishing

Areal surface roughness Areal surface roughness

P-V: 8517.6nm

P-V: 12.3nm


RMS: 756.1nm

RMS: 0.7nm

In just 10 minutes...

- Remove 10 μ m
- Improve surface figure
- Improve surface roughness by 100x


The role of VIBE in modern optical manufacturing processes



Outline

- Introduction
 - Mid-Spatial Frequency (MSF) Errors
 - VIBE Technology
- Characterization of MSF Errors
- MSF Error Removal with VIBE

Characterizing Mid-Spatial Frequencies




Traditional surface form measurements are not adequate

Possible Methods for MSF characterization:

- Visual Inspection
- Slope
- Zernike Residuals
- Residual after Filtering
- PSD – power spectral density
- Wavelets

Visual Inspection works well for this part, but it still does not give a quantitative result.

Slope can be a useful characterization




- Specified in either PV or RMS
- Integration length determines feature size
- Default ANSI integration length is 4% of clear aperture
 - 0.5 – 3mm typical for characterizing MSF errors






Residuals – RMS, PV of shape after removing form

FFT filtering in the range of interest




Removed first 36 Zernike Terms




Power Spectral Density

PSD of line traces across sample. Tells you how much energy of sample is in each spatial frequency. Area under curve at frequency of interest is the rms of sample.




Can be difficult to obtain consistent results over various computation methods.



Wavelets

A wavelet analysis tells you the quantity of each wavelet in a signal



A set of wavelets (sized in the area of interest) is formed and using correlation techniques, we can determine how much of that wave is in the height map. That value can be used as the testing parameter.

Additional work to be done in this area





Outline

- Introduction
 - Mid-Spatial Frequency (MSF) Errors
 - VIBE Technology
- Characterization of MSF Errors
- MSF Error Removal with VIBE


Implementing VIBE to remove MSF errors

- Current status
 - 2010 Phase I – complete
 - Flat surfaces
 - 2011 Phase I – three months into contract
 - Spherical surfaces
 - 2011 – 2013 Phase II – contract signed two weeks ago
 - Robust platform – move toward aspheric and cylindrical surfaces
- Examining different compliant mediums to determine optimum polishing pad composition
 - Material
 - Borosilicate glass
 - Initial surface – sub-aperture figure correction of plano or spherical surface
- Only remove nanometers of material
 - VIBE finishing step completed in less than 60 seconds

Initial Phase I Results: Reduction of MSF errors on flat surfaces







Second Phase I: Removing MSF errors on spherical surfaces




Radius of curvature requires a different motion on test platform

Initial spherical results show reduced MSF error, but form was altered




- More compliant lap is necessary

Proper pad compliance necessary to account for form mismatch





Non-compliant lap




Compliant lap

Higher compliant lap shows more desirable results

Initial surface



After VIBE



	PV (nm)	RMS (nm)	Peak Slope (wv/cm)	RMS Slope (wv/cm)	Zernike Residual RMS (nm)
Initial	24.8	2.4	0.24	0.054	0.0024
After VIBE	21.6	3.6	0.16	0.051	0.0024

Planned work for Phase II

- Build new platform
 - Flexibility to accommodate multiple surface forms
- Rotational and Raster MSF error removal
 - Spheres
 - Cylinders
 - Aspheres
 - Freeforms
- VIBE finishing to reduce grain decoration on polycrystalline materials
- Interrogate MSF characterization methods

Conclusions and Future Work

- VIBE finishing can reduce the appearance of MSF errors on flat and spherical rotationally polished surfaces
- Continued work on eliminating MSF errors
- Future work: extend technology to spheres, cylinders, aspheres and conformal optics

Acknowledgements

- The authors would like to thank
 - Ron Eng (NASA)
 - Phil Stahl (NASA)
 - John Lehan (Univ. of Baltimore Maryland)
 - Peter Blake (NASA)
 - NASA SBIR program for funding this work

Eliminating Mid-Spatial Frequency Errors with VIBE

Optimax Systems, Inc.
Ontario, NY

INNOVATION

The Optimax VIBE process is a full-aperture, conformal polishing process incorporating high frequency and random motion to *eliminate mid-spatial frequency (MSF) errors* created by deterministic polishing in a VIBE finishing step while maintaining low spatial frequency form accuracy.

ACCOMPLISHMENTS

- ◆ Showed feasibility on flat surfaces
- ◆ VIBE finishing has been shown to reduce the severity of MSF errors
- ◆ We have incorporated repeatable interferometric methods to characterize MSF errors


FUTURE PLANS

- ◆ Build robust platform
- ◆ Extend process to non-spherical shapes


COMMERCIALIZATION

- ◆ Optimax VIBE™ Technology
- ◆ U.S Patent Number 6942554 B1
- ◆ Primary target applications: Optical imaging systems where small angle scatter would reduce performance quality
- ◆ Optimax currently provides high precision optics to the aerospace, defense, medical and imaging markets, VIBE technology will enhance our capabilities
- ◆ Current customers are designing all spherical optical systems due to Asphere manufacturing limitations (MSF errors)
- ◆ MSF errors are formed during deterministic sub-aperture polishing processes. MSF errors cause small angle scatter and flare in optical systems.
 - ◆ VIBE Finishing will eliminate these undesirable MSF errors

VIBE Finishing results on a flat surface



Introduction of VIBE into today's optical manufacturing process



GOVERNMENT/SCIENCE APPLICATIONS

NASA:

- ◆ X-Ray Telescopes:
 - ◆ IXO – slumping mandrels, produce surfaces less than 1.4nm rms between 2-20mm spatial frequency range.
- ◆ Exo-Planet Imaging Systems:
 - ◆ Minimize scatter on primary and secondary mirrors, specifically less than 1nm rms in 4-50 cycles/aperture range

Non-NASA:

- ◆ High Energy Laser Systems, EUV Optics (Lithography), Imaging Systems and X-Ray Synchrotron Optics

Contact: Jessica Nelson
Optimax Systems, Inc.
585-265-1020 x276

Optimax Systems, Inc.

S2.05 Optics Manufacturing and Metrology for Telescope Optical Surfaces; proposal # S2.05-9386 and S2.05-8826

June 22, 2011